

GLOBBER

EXPLORER TRIKE • 6in1



INFANT TRIKE
TRICYCLE BÉBÉ
10-36M

MAX.
15kg
33lbs



GUIDED TRIKE
TRICYCLE GUIDE
18-36M



TRAINING TRIKE
TRICYCLE
D'ENTRAÎNEMENT
24-36M

MAX.
20kg
44lbs



BALANCE BIKE
DRAISIENNE
2-5Y



**FOR FULL ASSEMBLY, SAFETY
INSTRUCTIONS, SPARE PARTS,
AND WARRANTY, PLEASE
SCAN THE QR CODE.**

**IMPORTANT – READ CAREFULLY
AND KEEP THESE INSTRUCTIONS
FOR FUTURE REFERENCE.**

IMPORTANT – READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

IMPORTANT – À LIRE ATTENTIVEMENT ET À CONSERVER POUR FUTURE RÉFÉRENCE

WICHTIG – BITTE SORGFÄLTIG DURCHLESEN UND ZUR SPÄTEREN VERWENDUNG AUFBEWAHREN

IMPORTANTE: LÉALO ATENTAMENTE Y GUÁRDELO PARA FUTURAS CONSULTAS

IMPORTANTE – LEGGERE ATTENTAMENTE E CONSERVARE PER FUTURA CONSULTAZIONE

BELANGRIJK – LEES DIT AANDACHTIG DOOR EN BEWAAR HET VOOR TOEKOMSTIG GEBRUIK

IMPORTANTE – LEIA ATENTAMENTE E GUARDE PARA FUTURA CONSULTA

WAŻNE – PROSIMY O UWAŻNE PRZECZYTANIE I ZACHOWANIE NA PRZYSZŁOŚĆ

VIGTIGT – LÆS OMHYGGELIGT OG GEM TIL SENERE BRUG

TÄRKEÄÄ – LUE HUOLELLISESTI JA SÄILYTÄ TULEVAISUUDEN VARALLE

VIKTIGT – LÄS NOGGRANT OCH SPARA FÖR FRAMTIDA BRUK


ΣΗΜΑΝΤΙΚΟ – ΔΙΑΒΑΣΤΕ ΠΡΟΣΕΚΤΙΚΑ ΚΑΙ ΦΥΛΑΞΤΕ ΤΟ ΓΙΑ ΜΕΛΛΟΝΤΙΚΗ ΑΝΑΦΟΡΑ

ВАЖНО – ПРОЧЕТЕТЕ ВНИМАТЕЛНО И ЗАПАЗЕТЕ ЗА БЪДЕЩА УПОТРЕБА


DŮLEŽITÉ – POZORNĚ SI PŘEČTĚTE A USCHOVEJTE PRO PŘÍPADNÉ POZDĚJŠÍ POUŽITÍ


IMPORTANT – CITIȚI CU ATENȚIE ȘI PĂSTRAȚI ACEST DOCUMENT PENTRU REFERINȚE VIITOARE

FONTOS – KÉRJÜK, FIGYELMESEN OLVASSA EL, ÉS ŐRIZZE MEG KÉSŐBBI HASZNÁLATRA



ÖNEMLİ – DİKKATLİCE OKUYUN VE İLERİDE BAŞVURMAK ÜZERE SAKLAYIN
ВАЖНО – ПРОЧТИТЕ ВНИМАТЕЛЬНО И СОХРАНИТЕ ДЛЯ БУДУЩЕГО ИСПОЛЬЗОВАНИЯ
VIKTIG – LES NØYE IGJENNOM OG OPPBEVAR TIL SENERE BRUK
DÔLEŽITÉ – POZORNE SI PREČÍTAJTE A USCHOVAJTE PRE BUDÚCE POTREBY
重要提示——请仔细阅读并妥善保存以备将来查阅
重要 – 請仔細閱讀並妥善保存以備日後參考
重要 – よくお読みいただき、今後の参考のために保管してください
중요 – 주의 깊게 읽으시고 추후 참고를 위해 보관해 주십시오
هام – يرجى القراءة بعناية والاحتفاظ بهذه الوثيقة للرجوع إليها لاحقًا
ВАЖЛИВО – УВАЖНО ПРОЧИТАЙТЕ ТА ЗБЕРЕЖІТЬ ДЛЯ ПОДАЛЬШОГО ВИКОРИСТАННЯ
POMEMBNO – POZORNO PREBERITE IN SHRANITE ZA POZNEJŠO UPORABO
SVARĪGI – LASIET UZMANĪGI UN SAGLABĀJIET TURPMĀKAI IZMANTOŠANAI
SVARBU – ATIDŽIAI PERSKAITYKITE IR IŠSAUGOKITE ATEITIES REIKMĖMS
TÄHTIS – LUGEGE HOOLIKALT LÄBI JA HOIDKE SÄILITAMISEKS
VAŽNO – PAŽLJIVO PROČITAJTE I SAČUVAJTE ZA BUDUČU UPOTREBU









OK!


A.




B.




C.




D1.





D2.



A-B




B-C




OK!


C-D






OK!



OK!





OK!



OWNER'S MANUAL	ENGLISH
MANUEL D'UTILISATION	FRANÇAIS
BENUTZERHANDBUCH	DEUTSCH
MANUAL DEL PROPIETARIO	ESPAÑOL
MANUALE D'USO	ITALIANO
GEBRUIKSHANDLEIDING	NEDERLANDS
MANUAL DE INSTRUÇÕES	PORTUGUÊS
INSTRUKCJA OBSŁUGI	POLSKI
BRUGSVEJLEDNING	DANSK
KÄYTTÖOPAS	SUOMI
ANVÄNDARMANUAL	SVENSKA
ΕΓΧΕΙΡΙΔΙΟ ΧΡΗΣΗΣ	ΕΛΛΗΝΙΚΑ
ИНСТРУКЦИИ ЗА УПОТРЕБА	БЪЛГАРСКИ
NÁVOD K POUŽITÍ	ČEŠTINA
MANUAL DE UTILIZARE	ROMÂNĂ
HASZNÁLATI ÚTMUTATÓ	MAGYAR
KULLANIM KILAVUZU	TÜRKÇE
РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ	РУССКИЙ
BRUKERHÅNDBOK	NORSK
NÁVOD NA POUŽITIE	SLOVENSKÝ
使用说明	简体中文
使用說明	繁體中文
取扱説明書	日本語
설명서	한국의
دليل الاستخدام	عربي
ПОСІБНИК З ЕКСПЛУАТАЦІЇ	УКРАЇНСЬКИЙ
NAVODILA ZA UPORABO	SLOVENSKI
LIETOTĀJA ROKASGRĀMATA	LATVIEŠU
VARTOTOJO VADOVAS	LIETUVIŲ
OMANIKU MANUAAL	EESTI
KORISNIČKI PRIRUČNIK	HRVATSKI

OWNER'S MANUAL

ENGLISH

Please carefully read the instructions before assembling and using the product. Keep the instructions for future reference.

Be careful when unpacking and assembling the product.

This product must be assembled by a responsible adult.

Remove all the parts which are not necessary for play before giving the product to your child.

Warning! Do not step or stand on back of frame which will cause product overturned.

Tricycle mode: Warning! Not to be used by children over 36 months; insufficient strength to support.

Do not use on wet days, or on wet ground.

IMPORTANT – READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

- WARNING! Never leave the child unattended.
- WARNING! Ensure that all the locking devices are engaged before use
- WARNING! Do not let the child play with this product in infant trike mode
- WARNING! This seat unit is not suitable for children under 6 months
- WARNING! Always use the restraint system
- WARNING! Check that the pram body or seat unit or car seat attachment devices are correctly engaged before use;
- WARNING! This product is not suitable for running or skating;
- Don't attach any carrying accessory. Load attached to the handle and/or on the back of the backrest and/or on the sides of the vehicle will affect the stability of the vehicle.
- The parking device shall be engaged when placing and removing the children.
- Warning! The child is never to be left in the tricycle unattended.
- Warning! The child restraint system that is supplied with the tricycle is to be used.
- Warning! A parcel bag other than one recommended by the manufacturer is used, the tricycle may become unstable.
- Warning! The tricycle will become unstable if the manufacturer's recommended load is exceeded.
- Warning! The tricycle will become unstable if a parcel bag or parcel rack is used when there is no provision for one.
- Braking for balance bike: The balance bike can be braked with the feet. The child can stop the movement by stopping walking or running. Make sure your child is always able to stop at the speed produced and wears suitable footwear.

Inspection, maintenance and cleaning

- Check all hardware during usage period and tighten as required. It is particularly important that this procedure be followed at the beginning of each use. If these checks are not carried out, the trike could overturn or otherwise become a hazard. Replacement should be made in accordance with the manufacturer's instructions.
- Clean trike with a slightly damp cloth (cold water) and mild soap. Never use a corrosive or abrasive substance to clean the product.
- Vehicle shall be used only for one child which it has been designed.
- Accessories which are not approved by the manufacturer shall not be used. – Only replacement parts supplied or recommended by the manufacturer/distributor shall be used.
- Maximum child's weight: 15kg for Infant trike; 20kg for other modes.
- Children should be supervised by adult while riding this product. Special care should be taken to instruct children in safe riding.
- Do not use on the public highways, examples of safe riding area: To be used on flat and no gravel areas (playground, Public Square)
- Do not use this product near a staircase, on a slope, on a road or on a wet surface.
- The product should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.
- Regular maintenance maintains the safety of the toy.
- Check the product periodically to identify any loose or dislocated elements, particularly the wheels, screws, handlebars, bolts and connecting parts
- Periodic cleaning will extend the life of the product. Wipe the product clean with a dry cloth.
- Regularly check for abrasions and avulsions.
- Regularly check that parts are not broken or damaged; if this happens, stop using this product. Repair or remove any damaged parts of components. Remove any sharp edges created through use.
- Regular checks can prevent accidents.
- No modifications other than those in accordance with the instructions for use shall be made.
- When self-locking nuts and other self-locking fixings can lose their effectiveness after disassembly/reassembly.

For full assembly, safety instructions, spare parts, and warranty, please scan the QR code.

WARNING:

TO AVOID SERIOUS INJURY: Continuous adult supervision required; never use near motor vehicles; never use near streets, swimming pools; hills; steps, or sloped driveways; always wear shoes when using the product. Never allow more than 1 rider. Adult assembly required. Choking hazard to children under the age of 3 year – contains small parts prior to assembly.

ATTENTION:

POUR ÉVITER DES BLESSURES GRAVES : la surveillance permanente d'un adulte est requise ; ne jamais utiliser à proximité de véhicules à moteur ; ne jamais utiliser à proximité des routes, des piscines, des pentes, des marches ou es allées en pente ; toujours porter des chaussures lors de l'utilisation du produit. Ne jamais autoriser plus d'une personne sur le produit.

Un adulte est requis pour l'assemblage du produit. Risque d'étouffement pour les enfants de moins de 3 ans - contient de petites pièces avant l'assemblage.

WARNING:

- Not to be used by children over the age of 5 years due to size limitation.
 - Tricycle mode: Intended for children 10 months to 36 months. Walking bike mode: Intended for children 2 - 5 years.
 - Maximum child's weight: 33 lbs (15kg) / 44 lbs (20kg).
 - Plastic bags can be dangerous. To avoid suffocation, Keep plastic bags away from babies and children.
 - Instruct children on proper use of this product before allowing them to ride.
 - This product is not to be used in a manner other than for which it is intended.
 - This product is intended for outdoor domestic family use only.
 - It is recommended that rider always wear a properly fitted helmet that complies with U.S. Consumer Product Safety Commission (CPSC) Standard 16 CFR 1203.
 - Do not step or stand on back of frame which will cause product overturned.
 - Do not attempt to modify the product . For help contact Globber USA consumer service.
- Importer: Globber USA - 50 Fountain Plaza, suite 1400, Buffalo, New York, 14202 USA.



ID DEVELOPMENT LIMITED
Room 701, 7/F, Peninsula Centre,
67 Mody Road, Tsimshatsui,
Kowloon, Hong Kong

GLOBBER FRANCE SAS
66 rue de l'industrie
01120 Montluel - France

globber.com

Ref.: 835

Made in China
Fabriqué en Chine

IM_835-31L_2607